

## **Technical data sheet**

2620

# **NEUTREX** Liquid laundry neutraliser

## DESCRIPTION

**NEUTREX** is a phosphate-free high neutralizing capacity sour, formulated the most economical use in commercial and on premise laundries.

**NEUTREX** treats fabrics gently and adjusts pH of garments to minimize potential skin irritation and fabrics browning.

#### **APPLICATIONS**

**NEUTREX** is recommended for all Washer Extractors and Tunnel Washers equipped with automatic dispensing equipment.

**NEUTREX** may be used for all classifications of coloured and white linens.

## PRODUCT BENEFITS

- Phosphate-free
- Minimizes the potential skin irritation from fabrics
- Increases productivity of the finishing process
- Reduces the need for special fabric treatments.
- Cost-effective

## PHYSICAL PROPERTIES

Appearance	
Colour	Green
Specific Gravity @ 20°C	
pH (1%)	$2.40 \pm 0.05$

## **DIRECTIONS FOR USE**

To follow use of **MAGNUM** (**OH-5328**) in the wash zone, **NEUTREX** is normally used at a concentration of 1-3ml /Kg dry wash load in the sour operation, dependent upon residual alkalinity encountered. Higher dosage of **NEUTREX** may be required if high dosage of **VIPER PLUS** (**OH-4610**) and **MAGNUM** (**OH-5328**) are used in the washing. Trials are needed to achieve the right dosage for neutralizing the water to pH 6.5 - 7.0.

#### ORAPI APPLIED (S) PTE LTD

No 26 Tuas Avenue 13 Singapore 6387992 Tel: +65 6265 2888 - Fax: +65 6268 6474 Inquiries: sin.sales@orapi.com.sg Web Site: <u>www.orapiasia.com</u>

#### TDS 2620 / 002 -07/03/2016

The ORAPI Group designs, manufactures and markets, Technical Solutions for Professional Hygiene and Industrial Maintenance. The Group is listed on NYSE Euronext and represented in over 150 countries. ORAPI is certified ISO 9001 and 14001.

1/2

2





## **APPROVAL**





Reference Number: CPRE-2015-005086

## **STORAGE & SAFETY**

Two years stored in unopened original packaging in a cool and dry environment and away from high heat or direct sunlight.

Avoid contact with skin and eyes. In case of contact, wash with soap and rinse skin and flush eyes with running water for at least 15 minutes. Seek medical attention if effects persist. If swallowed, DO NOT induce vomiting, give plenty of milk or water to drink. Seek medical attention. **Keep out of reach of children**.

#### For further information please refer to the Safety Data Sheet.

## PACKAGING

Ref: OH-2620-O2.....Pail 25L Ref: OH-2620-U2.....Drum 205L

## WARRANTY

The information contained herein is presented without guarantee or warranty and the Seller disclaims any liability incurred from the use thereof. Nothing contained herein is to be construed as a recommendation for any use in a commercial process not controlled by the Seller, nor for a use which is in violation of any existing patent, foreign or domestic, or of applicable laws and regulations. THE SELLER MARKS NO WARRANTIES, EXPRESS OR IMPLIED, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OR MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE, EXCEPT AS EXPRESSLY STATED IN SELLER'S SALES CONTRACT OR SALES ACKNOWLEDGEMENT FORM.

#### **ORAPI APPLIED (S) PTE LTD**

No 26 Tuas Avenue 13 Singapore 638992 Tel: +65 6265 2888 - Fax: +65 6268 6474 Inquiries: sin.sales@orapi.com.sg Web Site: <u>www.orapiasia.com</u>

#### TDS 2620 / 002 -07/03/2016

The ORAPI Group designs, manufactures and markets, Technica Solutions for Professional Hygiene and Industrial Maintenance. Th Group is listed on NYSE Euronext and represented in over 15 countries. ORAPI is certified ISO 9001 and 14001.

2/2

CORPORATE FOUNDATION ORAPP Hygiene is life