



QUICK WRAP

FAST CURING REPAIR BANDAGE

DESCRIPTION

QUICK WRAP is designed to make quick and effective repairs to cracks, fractures, casting and corrosion porosity in metal (ferrous and non-ferrous), plastic, concrete and asbestos clad piping carrying, oil, steam and most gases and solvents.

QUICK WRAP provides immediate repairs in emergency situations and cures in less than 10 minutes saving costly downtime.

QUICK WRAP has good temperature, pressure and chemical resistance and is quick and easy to use. Ideal for permanent repairs requiring maximum strength and security in chemical, manufacturing, engineering, marine, agricultural, greenhouse and food processing industries. Other applications, using reinforcements or splints include rebuilding broom handles, fishing rods, landing net poles and all manner of supports on furniture and equipment.

QUICK WRAP is ideal for low pressure repairs, however used with an intermediate repair system. **QUICK WRAP** can be used for high pressure repair.

APPLICATIONS

- **QUICK WRAP** allows on the spot repairs to metal, plastic, concrete or asbestos pipes, tubes, rods, stanchions etc. Emergency repairs to oil, gas and water supply lines, sludge, slurry, water and steam pipes, waste product pipes, chemical lines and many other applications.
- Advanced water activated polyurethane resin. **QUICK WRAP** sets in under 10 min and is water/fluid compatible.
- Knitted aramid fibre composition. **QUICK WRAP** stretches around joints, fittings and elbows.
- No mixing or measuring. **QUICK WRAP** is ready for use after soaking in room temperature water for just 10 seconds.
- **QUICK WRAP** is safe and easy to use and is food safe when cured.
- Suitable for pipes up to 100mm external diameter.

APPROVALS

- **Conforms to:** UTE C 33-011 and HN 25-S-0 (French Nuclear Power).
- **QUICK WRAP** fulfils all the requirements of the water byelaws scheme approval (BS6920), which tests the effects of the cured bandage in the pressure of potable water.

DIRECTIONS FOR USE



1. Shut down pipes and hoses before repair and prepare the surface by cleaning and abrading lightly the surrounding area. Where necessary use one of ORAPI's intermediate repairs, e.g. Repair putty, or cut off 75 mm of bandage before wrapping and force it into the crack/leak to form a plug.



2. The product is supplied in a sealed foil bag to ensure maximum life when not in use (shelf life > 12 months). Having selected the correct sized bandage for the repair. Tear off the top of the bag. A minimum of nine windings must be achieved. If this is not possible use a second bandage



3. Ensure that gloves are being worn the remove the bandage from the foil bag. To activate the bandage soak in fresh warm water or salt water for 10 seconds squashing the product in the hand whilst submerged.



4. Curing begins immediately upon opening the package therefore it must be applied quickly to the repair area.



5. Continue to apply pressure to the bandage by wetting the outside of the bandage in the direction of the wrap until the bandage begins to set.



6. Leave the product to harden. It should be fully cured after 1 hour; however cure speed can be vary dependent upon temperature and humidity.

STORAGE & SAFETY

At least two years in its original packaging between 5° C and 25°C. Keep in a dry place. Avoid contact with eyes. Keep out of reach of children

For further information, please consult the Materials Safety Data Sheet

PACKAGING

10cm x 3.6 m

Ref. O-309-L5

x 1

WARRANTY

The information contained herein is presented without guarantee or warranty and the Seller disclaims any liability incurred from the use thereof. Nothing contained herein is to be construed as a recommendation for any use in a commercial process not controlled by the Seller, nor for a use which is in violation of any existing patent, foreign or domestic, or of applicable laws and regulations. THE SELLER MARKS NO WARRANTIES, EXPRESS OR IMPLIED, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OR MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE, EXCEPT AS EXPRESSLY STATED IN SELLER'S SALES CONTRACT OR SALES ACKNOWLEDGEMENT FORM.