

**GARCIN®**  
**BACTINYL AIRONE-SHOT**  
*Hospital-Grade Disinfectant & Deodorant*




**DESCRIPTION**

**GARCIN® BACTINYL AIR ONE-SHOT** is a powerful **Bactericidal, Fungicidal** and **Virucidal** disinfectant, formulated to purify the air and disinfect environmental surfaces.

**GARCIN® BACTINYL AIR ONE-SHOT** controls and reduces the spread of germs (airborne virus and bacterias) that cause epidemics and diseases.

**APPLICATIONS**



**BACTINYL AIR ONE-SHOT** is recommended for use in areas where people are closely associated for extended periods of time and where there is a heavy flow of pedestrian traffic: hospitals, nursing homes, clinics, schools, childcare centres, hotels and motels, restaurants, plants and factories and businesses with large work forces.

**BACTINYL AIR ONE-SHOT** is recommended when widespread outbreaks threaten and is effective to control the spread of virus and bacterias.

**PRODUCT BENEFITS**

- Versatile (air / surfaces).
- 3-ways action: Cleans, Disinfects and Deodorizes in one step.
- Wide spectrum of disinfection : Virucidal, Fungicidal and bactericidal activity.
- Controls the spread of influenza virus (H1N1, H5N1) and Coronavirus (SARS-Cov2\*, MERS).
- Destroys many airborne bacterias causing the common cold & other respiratory ailments.
- Improves indoor air quality and neutralizes odours from any source.
- Reduces the Hazard of cross infections.
- Acts instantly and remains effective for long periods.
- **One-shot covers up to 90m3.**
- Easy to use.

**PHYSICAL PROPERTIES**

Appearance ..... Liquide in aerosol  
Density ..... <1

**Active Substances:** Propan-2-ol (n°CAS : 67-63-0) : 37.67% alkyl (C12 C14) ethylbenzylammonium chloride (n°CAS : 85409 23-0) : 0.34%, alkyl (C12-C18) dimethylbenzylammonium chloride (n°CAS : 68391-01 5) : 0.34%.



## MICROBIOLOGIC ACTIVITIES

- Complies with biocidal Directive TP2.
- Bactericidal : EN 1276, EN 13697 and EN 13727 (5 min)
- Fungicidal : EN 1650 and EN 13697 (15min).
- Viricidal : EN14476 (5 min) on enveloped viruses : Coronavirus, H1N1, Vacciniavirus model MVA.

## DIRECTIONS FOR USE

**BACTINYL AIR ONE-SHOT** allows to treat up to 90m<sup>3</sup>.

Shake the aerosol before use and place the aerosol vertically in the center of the room. Engage the diffuser and exit the room by closing it. The product is released automatically and in full. Leave on for 15 minutes. Ventilate 30 to 60 minutes before returning to the premises. Renew the application after each use of the premises or daily.

Before using **BACTINYL AIR ONE-SHOT**, food and food packaging materials must be removed or carefully protected. Treated food contact surfaces and equipment must be thoroughly cleaned and rinsed with potable water prior to reuse.

## STORAGE & SAFETY

Three years stored in closed original packaging in a cool and dry environment.

Keep only in well ventilated areas between +5°C and +35°C.

Well ventilate after use. Use biocides with caution.

*For further information please refer to the Safety Data Sheet.*

## PACKAGING

Ref: OH-6030-A1 ..... 12 x 150 ml

## WARRANTY

*The information contained herein is presented without guarantee or warranty and the Seller disclaims any liability incurred from the use thereof. Nothing contained herein is to be construed as a recommendation for any use in a commercial process not controlled by the Seller, nor for a use which is in violation of any existing patent, foreign or domestic, or of applicable laws and regulations. THE SELLER MARKS NO WARRANTIES, EXPRESS OR IMPLIED, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OR MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE, EXCEPT AS EXPRESSLY STATED IN SELLER'S SALES CONTRACT OR SALES ACKNOWLEDGEMENT FORM.*